


Fast Lights LEDs

Chameleon G2 Remote Keyfob Instructions



Button:

Function

- | | | |
|----------|----------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| A | On/Off | |
| B | Color/Mode | Press the "B" button to select your favorite color. After rotating through the solid colors the lights will enter a dynamic mode that rotates through all colors automatically. There are 3 speeds of this function then the LEDs will return to solid (Static Mode) |
| C | Strobe/Crazy | Press "C" to choose Fast, Medium or Slow Strobe or Crazy Jump Mode. Additional presses returns to Static mode. |
| D | Breathe /Fade | Press "D" button to place controller in Breathe or Fade mode. |